


# Ultra Oil Wiring Diagram



- Connect HM black wire to terminal 10
- Connect HM white and brown wires to terminal 11
- If factory installed jumper remains between terminals 18 & 19, remove jumper. Connect HM yellow wire to terminal 18 and HM red wire to terminal 19
- If limit(s) have been installed between terminals 18 and 19, remove limit wire from terminal 19. Connect HM yellow wire to limit wire that was just removed, connect HM red wire to terminal 19

HeatManager with Weil-McLain Ultra Oil  
Boiler

